



industrial engines

**section 3.1**

**new 8361 series**

**workshop manual**

Publication No L32023007  
Date 02 - 1995

**IVECO *aifo***

The data contained in this publication may not have been updated following modifications carried out by the manufacturer, at any time, for technical or commercial reasons and also to conform to the requirements of the law in the various countries

This publication supplies features and data together with the suitable methods for repair operations to be carried out on each single component of the engine.  
Following the supplied instructions and using the inherent specific fixtures, a correct repair procedure will be obtained in due time, protecting the operators from all possible accidents  
Before starting any repair, be sure that all accident prevention devices are available and efficient  
Therefore check and wear what indicated by the safety provision protective glasses, helmet, gloves, safety shoes  
Before use, check all work, lifting and transport equipment

## INDEX

8361SRI12

Page

GENERAL.....	1
DATA ON ASSEMBLY CLEARANCES.....	2
TOOLS.....	8
TIGHTENING TORQUES.....	9
FAULT DIAGNOSIS.....	10
DISMANTLING THE ENGINE ON THE BENCH.....	21
REPAIR OPERATIONS.....	26
CYLINDER BLOCK.....	26
INJECTION PUMP DRIVE.....	31
POWER STEERING PUMP DRIVE.....	32
CRANKSHAFT.....	34
CONNECTING ROD/PISTON ASSEMBLY.....	40
ASSEMBLING THE CONNECTING ROD/PISTON ASSEMBLY.....	43
TIMING GEARS.....	45
FITTING THE INJECTION PUMP AND SETTING THE TIMING.....	47
CYLINDER HEAD - DISMANTLING OF VALVES - VALVES.....	48
VALVE GUIDE.....	49
VALVE SPRINGS - FITTING THE CYLINDER HEAD.....	52
PUSHRODS - ROCKER SHAFT - ROCKERS.....	53
LUBRICATION - HEAT EXCHANGER.....	55
OIL FILTER - COOLING SYSTEM.....	56
OVERHAULING THE TURBOCHARGER TYPE KGK,K27.2.....	61

## ENGINE SPECIFICATIONS

Engine type. ....8361SRI12  
 4 - stroke Diesel with direct injection  
 Cylinders, number and arrangement. ....6, in line  
 Bore x stroke. ....112 X 130 mm  
 Displacement. ....7,7 l  
 Compression ratio. ....17,6:1  
 Maximum rating(\*) .....198 kW(270 CV)  
 At. ....2200 rpm  
 Intermittent rating. ....184 kW(250 CV)  
 At. ....2200 rpm  
 Continuous rating (10% overload capacity) ... 165 kW(225 CV)  
 At. ....2100 rpm  
 Engine rotation:  
 (see from flywheel) .....CCW

## (\*) ISO Fuel Stop Power

- Ambient reference conditions:  
 ISO 3046/1; 25°C; 100 kPa; 30% relative humidity

## TIMING

## Valve Timing:

- Intake  
 opens: before T.D.C .....17° 32'  
 closes: after B.D.C .....38° 44'  
 - Exhaust  
 opens: before B.D.C .....53° 08'  
 closes: after T.D.C .....13° 37'

Clearance between valves and  
 rockers for timing checks .....0,40 mm

Operating clearance between valves and rockers, cold engine;  
 - intake and exhaust. ....0,40 ± 0,05 mm

## FUEL SYSTEM

In line injection pump type PES

Fixed injection pump delivery start advance .....15° ± 30'  
 Fuel injectors setting .....240 + 8 bar  
 Firing order. ....1-5-3-6-2-4

## TURBOCHARGING

The engine is supercharged by a turbocharger driven by the exhaust gases.

Cooling intake air with air-water heat exchanger

The turbocharger is lubricated with the engine oil under pressure.

## LUBRICATION

Minimum oil pressure:

- at full throttle. ....3,5 kg/cm<sup>2</sup>  
 - when idling. ....1 kg/cm<sup>2</sup>

## COOLING SYSTEM

Forced water circulation controlled by centrifugal pump.  
 Water temperature controlled by thermostat.  
 Water filtering with multiple recycle filter.  
 Radiator cooling fan driven by V-belt.

## STARTING













By starter motor.











## ELECTRIC SYSTEM

- Voltage. ....24 V  
 - Self-regulated alternator. ....30 A  
 - Starting motor power. ....4 kW  
 - Battery (optional). ....2, each 110 Ah


















**DATA ON ASSEMBLY CLEARANCES**

**CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS**













		mm	
	Measurement dimension Bores for cylinder liners	X Ø 1	165 – 170 120,470 ÷ 120,500
	Cylinder liners outside diameter length	Ø 2 L	120,470 – 120,490 --
	Cylinder liners – crankcase housing		- 0,02 – + 0,03
	Outside diameter	Ø 2	-
	Cylinder liners Inside diameter protrusion (measured under a load of 4000 kg)	Ø 3 X	112,000 – 112,022 0,16 – 0,25
	Pistons measurement height outside diameter housing for gudgeon pin	X Ø 1 Ø 2	22 111,853 – 111,867 42,013 – 42,019
	Piston – cylinder liner		0,133 – 0,169
	Piston diameter	Ø 1	-
	Piston protrusion	X	0,1 – 0,25
	Gudgeon pin	Ø 3	42,000 – 42,006
	Gudgeon pin – pin housing		0,070 ÷ 0,019
	Piston ring grooves	X 1* X 2 X 3	3,200 ÷ 3,230 2,540 – 2,560 4,030 ÷ 4,050
	*measured on the Ø of 1175 mm		








				mm
	Piston rings	S 1 <sup>x</sup>		3,075 – 3,095
		S 2		2,480 – 2,490
		S 3		3,975 – 3,990
		*measured on the Ø of 117,5 mm		
	Piston ring – grooves	1		0,155 – 0,205
		2		0,050 – 0,080
		3		0,040 – 0,075
	Piston rings			–
	Piston ring end gap in cylinder liner	X 1		0,15 – 0,30
		X 2		0,20 ± 0,45
		X 3		0,30 – 0,60
	Small end bush housing	Ø 1		45,946 – 45,971
	Big end bearing housing	Ø 2		76,698 – 76,718
	Small end bush diameter			
	outside	Ø 4		46,076 ± 46,114
	inside	Ø 3		42,020 ± 42,035
	Big end bearing shell (S=thickness)	S		2,070 – 2,080
	Small end bush – housing			0,068 ± 0,105
	Gudgeon pin – bush			0,014 ± 0,035
	Big end bearing shells			0,127 – 0,254 – 0,508
	Measurement dimension	X		125
	Maximum out-of-parallel error on connecting rod axes	≡		0,08

			mm
	Main journals	Ø 1	79,777 – 79,800
	Crankpins	Ø 2	72,477 – 72,500
	Main bearing shells	S 1	2,174 – 2,184
	Big end bearing shells (S=thickness)	S 2	2,070 – 2,080
	Main bearing housings	Ø 3	84,206 – 84,226
	Bearing shells – main journals Bearing shells – crankpins		0,038 – 0,101
	Main bearing shells		0,254 – 0,508 – 0,762 – 1,016
	Main journal, thrust bearing	X 1	50,000 – 50,050
	Main bearing housing for thrust bearing	X 2	43,000 – 43,074
	Thrust washer halves	X 3	3,378 – 3,429
	Crankshaft end float		0,068 – 0,294
	Thrust washer halves		0,127 – 0,254 – 0,508
	Alignment	1	≥ 0,10
	Ovality	2 1 – 2	± 0,25 0,008
	Taper	1 – 2	0,012

CYLINDER HEAD, VALVE GEAR		mm
	Valve guide housings in the cylinder head    Ø 1	16,000 – 16,018
	Valve guide  Ø 2 Ø 3	9,025 – 9,045 16,028 – 16,039
	Valve guides and seatings in the head	0,010 – 0,039
	Valve guides	0,2
	Valves  Ø 4 α  Ø 4 α	8,980 – 8,995 65° 15' ± 5' 8,980 ± 8,995 45° 15' ± 5'
	Valve stem and its guide	0,030 – 0,065
	Housing in head for valve seat  Ø 1  Ø 1	47,980 ± 48,020 42,980 ± 43,020
	Outside diameter of valve seat, angle of valve seat in cylinder head  Ø 2 α  Ø 2 α	48,100 – 48,120 65° ± 15' 43,100 ± 43,120 45° ± 15'
	Recessing of valves    X	0 – 0,3
	Between valve seat and head	0,04 – 0,08



		mm	
	Valve spring height		
	Free spring	H	84,9
	Under a load of N		
	618 N	H1	52
	912 N	H2	39,5
	Injector protrusion	X	$1 \pm 0,4$
	Camshaft bearing housings in crankcase		$\varnothing 1 \Rightarrow \varnothing 7$
	Outside diameter of camshaft bushes		$58,141 - 58,191$
	Inside diameter of bushes		$55,050 \pm 55,085$
	Bushes and housings in crankcase		$0,116 \pm 0,191$
	Camshaft bearing journals		$54,940 - 54,970$
	Bushes and bearing journals		$0,080 - 0,145$
	Effective cam lift		
		H	7,077
		H	7,373

		mm
	Tappet cup housing in crankcase Ø 1	18,000 – 18,027
	Outside diameter of tappet cup Ø 2	17,860 – 17,892
	Ø 3* * Ø for checking clearance	17,938 – 17,970
	Between tappets and housings	0,030 – 0,089
	Tappets	0,5 – 1,0
	Rocker shaft Ø 1	24,015 ÷ 24,036
	Rockers Ø 2	24,060 – 24,080
	Between rockers and shaft	0,024 – 0,065

## TOOLS

TOOL NUMBER	DESCRIPTION
99305049	Equipment for checking spring loading
99322230	Swivelling telescopic stand
99340205	Impact extractor
99341003	Single action bridge
99341009	Pair of brackets
99341015	Clamp
99342145	Extractor for injector holder case
99348004	Universal extractor, internal, 5 to 70 mm
99350108	Wrench for valve gear clearance adjustment screw
99360183	Tongs for fitting engine piston rings
99360292	Installing tool for fitting seal to valve guide
99360314	Tool for removing cartridge filters
99360321	Tool for rotating engine flywheel
99360351	Tool for locking engine flywheel
99360357	Tool for removing and refitting engine valves
99360419	Box with set of tools for recutting valve seatings
99360445	Tool for compression and measurement of cylinder liner protrusion
99360467	Adaptor for checking cylinder compression (to be used with 99395682)
99360481	Drift for removing valve guide
99360495	Drift for fitting inlet valve guide (use with 99360481)
99360496	Drift for fitting exhaust valve guide (use with 99360481)
99360500	Crankshaft lifting tool
99360503	Rings for lifting cylinder block
99360595	Hoisting beam for removing and refitting engine
99360605	Ring clamp for inserting standard and oversize pistons into the cylinders
99360722	Tool for retaining cylinder liners
99360723	Tool for extracting cylinder liners
99361034	Brackets for securing engine to swivelling stand 99322230
99365063	Tool for refitting injector holder cases
99370005	Handle for drifts (interchangeable)
99370454	Installing tool for fitting crankshaft front seal (use with 99370005)
99374195	Installing tool for fitting crankshaft rear seal (use with 99370005)
99390311	Reaming tool for valve guide
99390425	Tap for threading injector holder cases to be extracted
99394017	Reamer for reconditioning lower part of injector holder case (use with 99394019)
99394018	Cutter for reconditioning injector seating housing (use with 99394019)
99394019	Pilot bush
99395216	Pair of gauges
99395363	Tee square assembly for checking connecting rod distortion
99395682	Diesel engine cylinder compression tester
99395687	Bore micrometer (50 – 175 mm)
99395850	Torque wrench for checking belt tension

**TIGHTENING TORQUES**

PART	TORQUE	
	Nm	Kgm
Cylinder head attachment bolt	◆ 1st stage preliminary torque	118 (12)
	2nd stage preliminary torque	118 (12)
	3rd stage angle	$90^{\circ} \pm 3^{\circ}$
	4th stage angle	$90^{\circ} \pm 3^{\circ}$
	5th stage angle	$45^{\circ} \pm 3^{\circ}$
Main bearing cap attachment bolts	◆ preliminary torque	60 (6)
	angle	$120^{\circ}$
Big end cap attachment bolts	◆ preliminary torque	40 (4)
	angle	$35^{\circ}$
Flywheel attachment bolts	◆ preliminary torque	100 (10)
	angle	$60^{\circ}$
Rocker shaft pedestal securing nut	◆ preliminary torque	50 (5)
	angle	$90^{\circ}$
Damper hub attachment screw	◆ preliminary torque	450 (45)
	angle	$120^{\circ}$
<hr/>		
Screw attaching the sump and shroud support bracket to the front cover		13 (1,5)
Screw attaching the sump to the crankcase, front cover and rear cover		13 (1,5)
Screw attaching the sump and bracket for heat exchanger water inlet pipe to crankcase		13 (1,5)
Screw attaching the sump and bracket for engine breather pipe to crankcase		13 (1,5)
Screw attaching the oil filter body mounting to the crankcase		130 (13)


◆ Lubricate the thread with engine oil

FAULT DIAGNOSIS


Main engine operating faults .

- 1 - Engine will not start
- 2 - Engine overheats
- 3 - Engine lacks power
- 4 - Engine emits black or dark grey smoke
- 5 - Engine emits grey (whitish) smoke


- 6 - Engine emits blue smoke
- 7 - Abnormal knocking from the engine
- 8 - Engine stops
- 9 - Engine exceeds maximum rpm
- 10 - Oil pressure too high or too low
- 11 - Excessive fuel consumption




(continued)



(continued)




(continued)




(continued)







(continued)




(continued)




(continued)




(continued)




(continued)



(continued)




**DISMANTLING THE ENGINE ON THE BENCH**




34968

Secure the engine to the swivelling stand 99322230 (2) by means of brackets 99361034 (1). Drain the lubricating oil from the sump.




34969

Detach the oil level dipstick sleeve (1).




34970

Detach the pipe from the starter heater, the pipe (5) from the injection pump (6), the pipe (3) from the fuel return pipe (4) from the injectors.




34971

Detach the pipe (2) from the inlet manifold (1) and from the LDA (3), pipes (4, 6) from the fuel filter support (5) and from the injection pump (8), pipe (7) from the injection pump. For removing the fuel filters, use tool 99360314.



34972


From the injectors (2), detach the fuel return pipe (4) and the delivery pipes (1). Remove the injectors (2). Remove the inlet manifold (3).



34973


From the turbocharger (2), remove the air duct. Remove the oil pipe (4) from the support (6) and pipe (5) from the connection on the crankcase. Remove the exhaust manifold (3) complete with turbocharger.






34974

Remove the pipe (3) from the oil breather (2) and from the crankcase  
Remove the valve gear covers (1)




34975

Remove the inhibitor filter (6) using tool 99360314 Detach the coolant pipes (1) from the filter mounting (5) and from the water pump (2) and from the water pump (2) Take off the filter mounting




34976

Remove the fan shroud (2), the viscostatic fan (3), the alternator (1) and its drive belt




34977

Remove the alternator bracket (1) Remove the flange (3) from the water pump (4), detach the pipe (2) from the thermostat housing (5) and remove the housing




34978

Remove the rocker shaft (1)  
Remove the caps from the ends of the valves and withdraw the push rods (2)




34979


Remove the cylinder head bolts (2) and, using tool 99360595 (1), lift off the cylinder head and remove the gasket




Fit the pillars 99360722 (4) for retaining the cylinder liners (5) to the crankcase. Using tool 99360314, remove the oil filters (3) from the heat exchanger (2) and remove the heat exchanger.




Mark the position (arrow) in which the injection pump (2) is fitted to the support (4). Fit tool 99365136 (1) to the unions of the injection pump (2) and remove the pump and starter motor (3).




Remove the pipes (1 and 5) and take off the water pump (4). Remove the alternator bracket (2) and the damper flywheel (3) with the front and rear pulleys.




Prevent the flywheel (1) from rotating by fitting tool 99360351 (2) to the flywheel and casing (3). Unscrew the screw (5) and take off the hub (6). Unlock the screws attaching the flywheel and remove the tool.



Remove the sump (1), brackets (2 and 4) and the timing gear cover (3).




Remove the pipe (3) and the oil strainer (1) from the crankcase and from the oil pump (2), then remove the oil pump.




Fit suitable handles to the flywheel so that it can be rotated  
 Position the engine vertically  
 Remove the big end caps and their bearing shells and then take the connecting rod/piston assemblies (1) out of the cylinder liners


**!** If on dismantling the connecting rod/piston assemblies it is found that the connecting rods and their caps are not numbered, the numbers should be stamped on them according to the numbering of the cylinders to which they belong




Unscrew the screws and remove the rear support (1) and the cover (2) with seal for the crankshaft




Using a suitable wrench, unscrew the main bearing bolts and remove the caps (1) with their bearing shells and the thrust washer halves



Remove the attachment bolts of the flywheel (1), fit suitable hooks (2) to it and remove the flywheel (1) from the crankshaft using a cable and lifting tackle




With the help of lifting tackle and tool 99360500 (1), raise the crankshaft (2) and remove it




34991

Remove the main bearing shells (1) and the thrust washer halves (2)  
Remove the jets (3)




34994

Withdraw the splined bush (3)




34992

Using an Allen key, unscrew the screws (1) securing the thrust plate of the camshaft (2) and remove the shaft from the cylinder block, taking care that the bearing bushes are not damaged during the operation




34995

Remove the cover (2) and oil pipe (1). Take off the screws (3) and the ring underneath them (4)




34993

Extract the tappets (1) from their housings




34996

Remove the shaft with gear (2) and gear (4). Take off the circlip (2) and remove the gear (1)



34997

Take off the adjustment shim (8)  
 Remove the locking tab of the strip (3) from nut (4) and take off the nut  
 Remove the screw (7), the union (1) and detach the pipe (2)  
 Remove the intermediate gear shaft (9), the support (6) for the injection pump drive shaft and the support (5) for the power steering pump drive shaft



34998


Using an appropriate extraction tool (3), extract the valve (2) for piston cooling jets from the crankcase (1)



When dismantling of the engine is complete, the parts dismantled must be thoroughly cleaned and checked for soundness

The following pages give instructions for the main checks and measurements to be carried out in order to determine whether the parts are fit for re-use on reassembly

**REPAIR OPERATIONS**  
**CYLINDER BLOCK**  
 Checks and measurements




34994

The inside diameter of the cylinder liners is checked to ascertain the amount of ovality, taper and wear by means of gauge 99395687 (2) fitted with a hundredths dial gauge (1), previously zeroed on the ring gauge (3) 112 mm in diameter




Where the 112 mm diameter ring gauge is not available, use a micrometer for this purpose




35000

The measurements must be carried out on each individual cylinder at three different levels and in two planes at right angles to each other, as shown in the figure  
 Maximum wear is found in line with the 1st measurement on axis B




35001

If maximum wear of more than 0.150 mm is found or maximum ovality of 0.100 mm compared with the values shown in the figure, the cylinder liner must be replaced since the internal surface of the liner has been given soft nitriding treatment, for which the operations of grinding, lapping or truing up are not permitted




35002

The plan shown in the figure gives the outside diameters of the cylinder liner and the internal diameters of its housing as well as the point at which these are to be measured  
The cylinder liners may if necessary be extracted and fitted several times in different housings



35003

Check that the mating surface (1) for the cylinder head is flat using a straight edge and a feeler gauge  
After ascertaining the areas of distortion, true up the mating surface, having first extracted the locating dowels (2) and cylinder liners (3), in accordance with the procedures indicated in section "540420 REPLACING CYLINDER LINERS", removing as little material as possible and bearing in mind that, after skimming, the protrusion of the piston from the cylinder liners must be 0.1 - 0.25 mm




35004

When the crankcase has been skimmed, restore the depth of the cylinder liner seating base so that the distance X is within the ranges of the subdivisions of the following classes

- I 90.000 - 90.010
- II 90.011 - 90.020
- III 90.021 - 90.030
- IV 90.031 - 90.040
- V 90.041 - 90.050



The dimension X is the average of three measurements carried out at three points 120° apart




35006

Stamp the class of measurement recorded on the crankcase at the points shown by the asterisks




Check the condition of the machining plugs in the cylinder block, if they are rusted or there is the least suspicion of leakage, replace them

### Replacing cylinder liners



35007

Position the parts (2 and 3) of tool 99360723 on the crankcase as shown in the figure, checking that the plate (3) of the tool is resting correctly on the cylinder liner  
Screw up the nut (1) and withdraw the cylinder liner from the crankcase




35008

Fit the cylinder liners, proceeding as described below


Thoroughly clean the cylinder liners and crankcase (3) with chloroethene so that there is no residue of the old adhesive,  
Degrease the parts to which adhesive is to be applied both on the crankcase and on the cylinder liners (see fig 45), on the basis of the classes stamped on the crankcase at the points shown by the arrows, fit the shim (2) of the thickness shown in the following table

CLASS	THICKNESS (mm)
I	3 18 ÷ 3 19
II	3 19 ÷ 3 20
III	3 21 ÷ 3 30
IV	3 31 ÷ 3 40
V	3 41 - 3 50




35009

Using a suitable tool, apply LOCTITE 576 evenly to the crankcase at the point indicated to form a ring 5 mm high, position the shim (2, fig 44) of the thickness shown in the table and insert the cylinder liner into the crankcase



35010

place the component of tool 99360445 (1) on a surface plate and zero the dial gauges




35011

- └ position the component of tool 99360445 (3) on the cylinder liner; fit the compression fixture (2) to the tool and secure it to the crankcase by means of the four bolts (4)
- tighten the screw (1) to a torque of 110 Nm (11 kgm)

This torque corresponds to a load of about 4000 kg. In these conditions read off from the dial gauge the protrusion of the cylinder liner which should be, as an average value, 0.16–0.25

**!** The maximum deviation of the average value recorded between each individual cylinder liner must be not more than 0.03 mm. If different values are found, replace the adjustment shim according to the procedures already described



35012


When fitting is completed, lock the cylinder liners (1) to the crankcase (2) by means of the pillars 99360722 (3)



Assembly of the engine must be finished within 10 hours of the application of LOCTITE 576 to the crankcase

VALVE GEAR


Camshaft  
Checking cam lift and journal alignment



32716

Arrange the camshaft (4) between the centres (1) and using the hundredths dial gauge (2) check the lift of the cams (3) which should be


- └ 7.077 mm for the inlet cam
- └ 7.373 mm for the exhaust cam



34991

Still with the camshaft (4) arranged between centres (1), check the bearing journals (3) for misalignment using the hundredths dial gauge (2), this must not be more than 0.020 mm. If a larger misalignment is found, replace the shaft






35014

MAIN DATA FOR THE CAMSHAFT


The surfaces of the bearing journals on the shaft and those of the cams must be perfectly smooth,

if instead there are signs of seizing or scoring, the shaft and its bushes should be replaced

REPLACING THE CAMSHAFT GEAR




To check the assembly clearance, measure the inside diameters of the bushes (fig 54) and the diameter of the camshaft journals (1, fig 51), the difference will give the actual clearance present. If clearances of more than 0.160 mm are found, replace the bushes and the camshaft too, if necessary



Check that the teeth of the camshaft gear (1) are not excessively damaged or worn, if they are, replace it. When fitting the new gear, it should be heated in an oven for 10' at a temperature of 180° and then shrunk onto the shaft (4), having first fitted the plate (3) and key (2) to the shaft


BUSHES



MAIN DATA FOR CAMSHAFT BUSHES AND THEIR HOUSINGS IN THE CRANKCASE

\* Dimension to be obtained after the bushes have been installed

**Replacing the bushes**



35015


The surfaces of the bushes must not show any signs of seizing or scoring, if they do, replace them. Measure the bush (1) inside diameters using a bore micrometer (2), if values greater than the tolerances are found, replace them. Use an appropriate tool to dismantle and assemble the bushes.



Fit the bushes so that the oil feed holes are lined up with those in the crankcase.


After fitting, ream the camshaft bushes using the appropriate tools to bring the internal diameter of the bushes to the nominal value indicated in figure 54.

**Replacing tappets**



35016

MAIN DATA FOR TAPPETS AND THEIR HOUSINGS IN THE CRANKCASE




32795

Replacement of the tappets due to excessive clearance in the housings involves fitting oversized tappets and reaming out the housings (2) using a suitable reamer (1).

Replacement tappets are supplied in standard size and 0.10, 0.20, 0.30 mm oversize.

**INJECTION PUMP DRIVE**  
**Replacing bushes**



35017


COMPONENT PARTS OF THE INJECTION PUMP SUPPORT

- 1 Injection pump support – 2 Shaft – 3 Adjustment shim – 4 Bush – 5 Adjustment shim – 6 Washer – 7 Circlip

Remove the retaining circlip (7) and remove the shaft (2), washer (6) and adjustment shims (4 and 5) from the support (1). Check the mating surfaces of the shaft (1) and of the bushes (4), these must not show any deterioration and the fit clearance must not be excessive.

The nominal diameter of the shaft is 49.984 – 50.000 mm.

**POWER STEERING PUMP DRIVE**  
Replacing the bushes




35018

If excessive fit clearance not attributable to the shaft is found, replace the bushes (2), using a suitable drift to remove and fit them




The bushes must be fitted with the joint facing the notch in the support for lubrication of the adjustment shim, and they must be recessed by 0.5 – 0.8 mm with respect to the faces of the support, as shown by the arrows

When the bushes (2) have been fitted, ream them out so that their nominal diameter is 50.025 – 50.050 mm  
Assemble the support components by reversing the dismantling operations



35019

Position a new seal on the injection pump support (1) and fit the support to the crankcase



35020

SECTIONAL VIEW OF THE POWER STEERING DRIVE SHAFT SUPPORT

- 1 Support, timing gear cover side – 2 Bush
- 3 Shaft – 4 Support, crankcase side – 5 Bush


Check the mating surfaces of the shaft (3) and bushes (2 and 5), these must not show any deterioration and the fit clearance must not be excessive

The nominal diameter of the shaft is 36.984 – 37.000 mm  
If excessive fit clearance not attributable to the shaft (3) is found, replace the bushes (2 and 5), using a suitable drift to remove and fit them




To fit the bushes (2 and 5), it is necessary to chill them in liquid nitrogen or heat the supports (1 and 4) so that there is a temperature difference of 270° C between the components. Maximum temperature permitted for the supports 350° C

When the bushes (2 and 5) have been fitted, ream them out with a reamer so that their nominal diameter is 37.050 – 37.073 mm




35021

Position a new seal (1) in the support (2) and fit the support to the crankcase



35022


On the opposite side, fit the power steering pump attachment flange



35023


COMPONENT PARTS OF THE PISTON COOLING JET VALVE

- 1 Circlip - 2 Dish - 3 Spring - 4 Valve - 5 Washer
- 6 Seal - 7 Valve body




35024

MAIN DATA FOR CHECKING THE SPRING FOR THE PISTON COOLING JET VALVE




35025

Fit a new seal to the valve body (6) and fit it to the crankcase. Secure the oil pipe (2) to the crankcase by means of the screw (5). Bend over the locking tabs onto the screws (3 and 5).




34993

Fit the tappets (1) into their housings




35027

Lubricate the bearings of the camshaft (1) and insert the shaft into the crankcase



Tighten the screws (1) securing the camshaft retaining plate (2)

### CRANKSHAFT




MAIN DATA FOR THE CRANKSHAFT MAIN JOURNALS AND CRANKPINS

**Measuring the main bearing journals and crankpins**

Before regrinding the journals, measure the main journals (2) with a micrometer (1) and establish on the basis of the scale of bearing undersizes (7) the diameter to which the journals must be reground


The classes of undersize are 0.254, 0.508, 0.762, 1.016 mm for the main bearing shells and 0.127, 0.254, 0.508 mm for the big end shells



35821

MEASURING THE MAIN BEARING JOURNALS

**⚠** Main bearing journals and crankpins are always all reground to the same undersize class so as not to impair crankshaft balance



35091

MEASURING THE CRANKPINS

During the grinding operation, take great care to comply with the values for the main journal and crankpin blend radii given in the following figures




Regrinding carried out on main journals or crankpins must be indicated by appropriate markings stamped on the side of crank

web no 1

For undersize crankpins the letter M

For undersize main journals the letter B


For undersize crankpins and main journals the letters MB



Rett = ground

35030


DETAIL OF MAIN JOURNAL BLEND RADII



Rett = ground

35031

DETAIL OF CRANKPIN BLEND RADII




Rett = ground

35032

DETAIL OF CENTRE MAIN JOURNAL BLEND RADII


**Checking main journal alignment**



35033

This check must be carried out after regrinding, if any, of the journals on the crankshaft (3) by positioning the crankshaft between centres (2) and using a hundredths dial gauge (1) for the check


- Main journal alignment maximum tolerance > 0.10 mm (total reading on the dial gauge)



6236

- Alignment of the crankpins with the main journals the centreline of each pair of crankpins and the centreline of the main journals must be in the same plane the maximum tolerance permitted at right angles to this plane is  $\pm 0.25$  mm
- For the distance between the axis of rotation of the shaft and the outer surface of the crankpins, the maximum tolerance permitted is  $\pm 0.10$  mm

**Replacing camshaft and oil pump drive gears**



35034


Check that the teeth of the gear (1) are not damaged or worn, if they are, remove them using a suitable extractor (3)

**!** When fitting the gear (1) to the shaft (2), there must be a temperature difference of 120 – 150°C between the two parts

**Fitting main bearings**


Replacement main bearings are supplied in inside diameter undersizes of 0.254, 0.508, 0.762, 1.016 mm

**!** Do not carry out fitting operations on the bearings



32728


Position the bearing shells (1) in the main bearing housings in the crankcase



34990

Using tool 99360500 (1) fit the crankshaft (2) onto the bearing shells


### Measuring main bearing assembly clearances



35035


The clearance between the crankshaft journals and the relevant bearings is checked by the plastigage method, proceeding as follows

- thoroughly clean the parts and remove all traces of oil
- arrange a strip of plastigage (3) on the main journals (2), parallel with the lengthwise axis
- fit the caps (1) together with the bearing shells to the relevant housings



35036


- tighten the main bearing cap securing bolts (1), having first lubricated them, to the prescribed torque of 60 Nm (6 kgm)



35037

- fit tool 99395216 (2) to the angle gauge wrench and tighten the bolts (1) a further 120°


### Checking crankshaft end float




35038

- Using a dial gauge with magnetic base (1), check the end float of the crankshaft, this should be 0.068 – 0.294 mm
- If a larger end float is found, replace the thrust washer halves with new ones of standard thickness or if necessary 0.127, 0.254 or 0.508 oversize







□ remove the main bearing caps (1)  
 The clearance between the main bearing shells and their respective journals is measured by comparing the width of the plastigage (3) at the point of greatest flattening with the scale divisions given on the package (2) containing the plastigage  
 The numbers given on the scale show the fit clearance in mm, which should be 0.068 – 0.794 mm



Position the thrust washer halves (1) on the 6th housing with the surface covered with anti-friction alloy towards the facing on the crankshaft




Fit the main bearing caps with bearing shells, before fitting the cap (1), position the halves of the thrust washer (2) with the surface covered with anti-friction alloy towards the facing on the crankshaft




⚠ To re-use the main bearing attachment bolts, check that at the point shown, the diameter **d** is 135 mm. If not, replace

Lubricate the thread and the head underside (→) with engine oil, fit and tighten to a torque of 60 Nm (6 kgm)




Further tighten the screws (1) by 1205, using tool 99395216 (2)

### Crankshaft rear cover




Using installing tool 99374195 (2) and handle 99370005 (1), fit the seal (3) to the rear cover (4)


Replace the flywheel ring gear



Lubricate the seal (2) and, having first fitted the gasket, fit the rear cover (1)




Fit the clutch bell housing (1) and tighten the securing screws to the prescribed torque




Check the seating surface for the clutch plate. If scoring is present, the flywheel must be skimmed


**!** Check that there are no cuts, swellings or stamping on the circular zone (X), if there are, replace the flywheel




If the teeth of the ring gear (1) fitted to the flywheel are badly damaged, replace the ring gear. Before fitting, the ring gear must be heated to a temperature of 80° C



Fit the flywheel (1) to the crankshaft




**!** To re-use the flywheel attachment bolts, check that at the point shown, the diameter  $d$  is 15.5 mm. If not, replace



35048


Prevent the flywheel (1) from rotating using tool 99360351 (3) and tighten the bolts (2), having first lubricated them with engine oil, to a torque of 100 Nm (10 kgm)



35049

Using tool 99395216 (2), tighten the bolts (1) further for 60°, remove tool 99360351 (3)


**CONNECTING ROD/PISTON ASSEMBLY**



35050


**COMPONENT PARTS OF THE PISTON/CONNECTING ROD ASSEMBLY**

- 1 Retaining clips – 2 Gudgeon pin – 3 Piston – 4 Piston rings –
- 5 Bolt – 6 Bearing shells – 7 Connecting – rod – 8 Bush



35051


Remove the piston rings (2) from the piston (3) using tongs 99360183 (1)



35052

The gudgeon pin (1) retaining clips (2) are removed using pliers (3)

**Piston**




35053

The diameter of the piston (1) is measured using a micrometer (2) to determine the assembly clearance




The diameter must be measured 22 mm from the base of the skirt



35054

The clearance between the piston and cylinder liner can also be measured using a feeler gauge (1)


**Gudgeon pin**



32618

The pins are fitted with clearance both in the small end and in the piston


**Conditions for correct gudgeon pin to piston fit**



32619

When fitting new pins, check the correct fit with the housing in the piston by carrying out the following check

- lubricate the pin and its housing in the piston bosses with engine oil
- holding the pin in a vertical position, insert it into the bosses in the piston
- it should be possible to insert the pin simply by pressing on it
- the pin should not drop out of the bosses by itself




35055

**MAIN DATA FOR THE PISTON, PISTON RINGS AND GUDGEON PIN**


\* The dimension is measured on the  $\varnothing 117.5$  mm

**Piston rings**




16552

Check the thickness of the piston ring (2) using a micrometer (1)




35057

Check the clearance between the piston rings (3) and the grooves on the piston (2) using a feeler gauge (1)



3513


The compression ring (2) in the first slot is wedge shaped. The clearance X between the compression ring and the groove is measured by positioning the piston (1) with the relevant ring in the cylinder liner (3) in such a way that the compression ring half projects from the cylinder liner



35058

The clearance between the ends of the piston rings (1) inserted into the cylinder liner (3) is measured using a feeler gauge (2)

**Connecting rods**




35059

MAIN DATA FOR THE CONNECTING ROD, BUSH, GUDGEON PIN AND BEARING SHELLS

\* Dimension to be obtained after installing the bush

**Checking connecting rod for distortion**




32738

Check that the connecting rod axes are parallel. The tolerance permitted is 0.08 mm measured at 125 mm from the lengthwise axis of the rod



Each connecting rod is marked on the body and cap with a number indicating that they fit together. Moreover, it may be stamped with the number of the cylinder in which it is fitted. In case of replacement, it is therefore necessary to number the new connecting rod with the same number as the one replaced.

**Bushes**



35060


The bush (2) is removed and refitted using the appropriate drift (1)



After installing the bush in the connecting rod small end, remove the part which protrudes at the side and then ream the bush to the specified diameter using reamer 99301044

**ASSEMBLING THE CONNECTING ROD/PISTON ASSEMBLY**


**Assembling connecting rod to piston**



35061

Position the piston (4) on the connecting rod (3) so that the words "LATO PUNTERIE" (TAPPET SIDE) (1) on the crown are on the opposite side to the number stamped on the connecting rod. Insert the gudgeon pin (2) and fit the retainer clips


**Checking connecting rod/piston for distortion**



35062


Check the connecting rod-piston assembly for distortion using fixture 99395363 (1) and a feeler gauge (2). The plane of the piston crown must be exactly at right angles to the plane of the fixture 99395363

**Fitting piston rings**



35051

The piston rings (2) are fitted to the pistons (3) using tongs 99360183 (1). The rings must be fitted with the word TOP facing upwards, and also the ring gaps must be located so that they are 120° apart




35064

Fit the bearing shells (1) to the connecting rod and to the cap



Do not carry out any fitting operations on the bearing shells




The connecting rod/piston assembly (1) is fitted into the cylinder liner using ring clamp 99360605 (2)  
Lubricate the parts concerned before fitting




- When fitting the connecting rod/piston assemblies into the liners, check that
- the connecting rod number corresponds to the number of its cylinder
  - the words "LATO PUNTERIE" (TAPPET SIDE) stamped on the piston crowns are facing the camshaft
  - the numbers on the connecting rods are facing away from the camshaft side
  - the piston ring gaps are staggered 120° apart


**Measuring crankpin assembly clearance**




- To measure the clearance, carry out the following operations
- thoroughly clean the parts and remove all traces of oil
  - position a strip of plastigage (2) on the crankshaft journals (1)



- lubricate the threads and undersides of the heads of the big end attachment bolts (1)
- fit the connecting rod caps (2) and, using a torque wrench, tighten the bolts (1) to a torque of 40 Nm




- using tool 99395216 (2), tighten the bolts (1) a further 35°



- remove the connecting rod cap and determine the clearance by comparing the width of the plastigage (2) with the scale divisions given on the package (1) containing the plastigage


**Fitting big end caps**



35070




To re-use the big end cap attachment bolts, check that at the point shown, the diameter X is 135 mm. If not, replace.



35071

Lubricate the big end bearing shells, the threads and undersides of the heads of the securing bolts (2).  
Fit the big end caps (3) and tighten the bolts (2), having first lubricated them with engine oil, to a torque of 40 Nm, then tighten further, by means of tool 99395216 (1), to an angle of 35°.

**Checking piston position**




35072

When fitting is complete, check the protrusion of the pistons (3) at TDC with respect to the cylinder liner face using a dial gauge (1) with magnetic base (3). The top lands of the pistons must project 0.1 – 0.25 mm above the face of the cylinder liners (2).

**TIMING GEARS**

**Checking and replacing the idler gear**




32637

Check the idler gear for damage and excessive tooth wear, replacing it if necessary.  
Check the contact surfaces of the bush (1) for scoring or signs of seizing, or excessive play on the bearing journal, if these are found, replace the bush (1) using a suitable drift.




**Replacement of idler gear bush**




35073

Fit the bush (1) so that it is recessed with respect to the face of the gear by 0,5 - 0,8 mm  
After fitting, ream the bush to obtain the nominal diameter shown in the figure



35074


Check the surface of the idler gear pin for damage or excessive wear. Check that the oil feed holes are not blocked



35075


Fit the pin (4) and position the adjustment shim (5) on it. Fit the injection pump drive gear (1), the power steering pump drive spindle and the support (3)

**Fitting the idler gear and setting the timing**




35076

Turn the flywheel (1) until the 0 stamped on it indicating TDC is in line with the pointer (2)




35077

Install the idler gear (2), locating it so that the numbers 1, 2 and 3 stamped on it line up with the same numbers engraved on the crankshaft gear (3), the camshaft gear (4) and the injection pump gear (1)




Fit the washer (1) and circlip (2), insert the oil pipe (4) in the support (3) and secure this to the pin (5) by means of the union (6)


### FITTING THE INJECTION PUMP AND SETTING THE TIMING



Turn the flywheel until the mark corresponding to  $15^\circ \pm 30'$  of injection advance is exactly lined up with the reference pointer (1)



Install the connection coupling (1) on the drive shaft housed in the support (2) remembering that it engages via a double dog and a double recess




Remove the inspection plug (2) from the injection pump, turn the shaft until the tappet relating to the above hole is in the start of delivery position

Using tool 99365136 (1), fit the injection pump, lining up the marks previously made when dismantling, and then secure the injection pump to its support



If the engagement dogs of the coupling joint and the injection pump shaft are found to be  $180^\circ$  out of phase, turn the crankshaft one revolution



Fit tool 99365134 (1) fitted with a dial gauge to the injection pump and rest the stylus (2) of the tool on the crown of the tappet

Zero the dial gauge when the tappet is at BDC

Turn the flywheel backwards about half a turn


Then turn the flywheel in the opposite direction and check that when the mark corresponding to  $15^\circ \pm 30'$

of injection advance on the flywheel is lined up with the reference pointer (2, fig 133), the plunger has travelled a start of delivery pre-stroke, read off from the dial gauge, of  $3.55 \pm 0.05$  mm

If a different value is found, loosen the screws (3) and adjust the cam so as to achieve the prescribed pre-stroke. Repeat the check and tighten the screws (3)

## CYLINDER HEAD

### Hydraulic leak test




35083

Before dismantling the cylinder head, carry out the hydraulic leak test

Fit the appropriate equipment to the cylinder head. Pump water heated to approx. 90° C and at a pressure of 4 – 5 bars into the cylinder head. Under these conditions, no leaks should be found, if they are, replace the cylinder head.

## DISMANTLING OF VALVES




35084

Rest the cylinder head on the workbench and, using tool 99360357 (6), apply pressure to the spring cup (2) so that by compressing the spring (3) the valve collets (1) can be removed. Then take off the upper cup (2), the spring (3) and the lower cup (4).

Repeat the operation on all the valves.

Turn the cylinder head upside down and withdraw the valves (5).

## Checking the mating surface of the head with the cylinder block




35086

The mating surface of the head with the cylinder block is checked using a straight edge and a feeler gauge. If values of more than 0.15 mm are found over the whole length of the surface, true up the head on a suitable surface grinder, removing as little material as possible.

## VALVES

### Removing deposits and checking valves




18625

Remove carbon deposits from the valves using a suitable wire brush.

Check the valves for signs of seizing or cracking and also, using a micrometer, check that the diameter of the valve stem is within the specified limits (see fig. 141). If not, replace the valves.

### Refacing the valves

If necessary, reface the seatings on the valves using grinding machine 99301014, setting an angle of  $45^{\circ} 15' \pm 5'$  for exhaust valves and  $65^{\circ} 15' \pm 5'$  for inlet valves removing as little material as possible.




35087

MAIN DATA FOR VALVES AND VALVE GUIDES

\* Dimension to be obtained after installing the valve guides


Checking valve stem to valve guide clearance



35088

Using a dial gauge (2) with magnetic base (1), check the play between the valve stem (3) and its guide. If excessive play is found, replace the valve and if necessary the valve guide


VALVE GUIDE



35427

FITTING VALVE GUIDES

A Inlet valve guide B Exhaust valve guide



35089

The valve guides are removed using drift 99360481 (1)

They are fitted using drift 99360481 (1) equipped with the adaptor (2)

□ 99360495, for inlet valve guides (3)


□ 99360496, for exhaust valve guides (4)

Adaptors 99360495 and 99360496 determine the correct fitting position for the valve guides in the cylinder head, if they are not available, the guides must be installed in the cylinder head so that they protrude from it by the amounts shown in figure 143



Replacement valve guides are also supplied with the outside diameter 0.2 mm oversize


Reaming the valve guides



35090

After installing the valve guides, ream the holes in the valve guides (2) using reaming tool 99390311 (1)

**Recutting the valve seats**




32749

Using the Hunger tool 99360419 (1), recut the valve seats in the cylinder head




The valve seats in the cylinder head are recut whenever the valves or valve guides are reconditioned or replaced



35092


RECESSING OF THE INLET AND EXHAUST VALVES FROM THE CYLINDER HEAD FACE



35093

After recutting the valve seats, check that the recessing of the inlet and exhaust valves with respect to the cylinder head face is 00 - 03 mm


**Valve leakage test**



35046


The leakage test on the valves in the cylinder head (1) is carried out using the appropriate equipment (2 and 3)

**Replacing injector holder cases**



35094

A defective fit between the injector and the case pressed into the cylinder head or between the case and the housing in the cylinder head causes a loss of compression or coolant loss. In the first case, the fault can be eliminated by reconditioning the case housing using cutter 99394018 (1) and bush 99394019 (2), remembering that the protrusion of the injector from the face of the cylinder head must be  $1 \pm 0.4$  mm




35095

In the second instance, the case must be replaced, proceeding as follows

- tap a thread in the case using tool 99390425 (1)




The stop bush (2) must be positioned about 9 mm from the end of the tool (1)




35096

□ using extractor 99342145 (1), extract the casing from the cylinder head




22408

Using a suitable tool (1), remove any copper residue left in the splines in the cylinder head




35097

Lubricate the seals (2), fit them to the case (1) and insert the latter into the housing in the cylinder head



35098


Spread the lower seating of the case (3) in the cylinder head using spreading tool 99365063 (1) and bush 99394019 (2)



35099

Ream the hole in the case (2) using reamer 99394017 (3) and bushes 99394019 (1)


**Checking injector protrusion**



35100


Check the protrusion of the injector (1) from the cylinder head face. If necessary, adjust the injector protrusion with respect to the cylinder head face by recutting the seating using cutter 99394018 (4) and bush 99394019 (1), the value should be  $1 \pm 0.4$  mm

**VALVE SPRINGS**



16587


Before fitting, the characteristics of the valve springs must be checked using tool 99305049, and the data on load and elastic deformation compared with those given for new springs in the following figure



35101


MAIN DATA FOR CHECKING THE VALVE SPRINGS

**Fitting the valves**



35102

Lubricate the valve stems (3) and insert them into their valve guides, using installing tool 99360292 (1), fit the seals (2) to the exhaust valve guides (4)




35084

On the cylinder head arrange the lower spring cup (4), the spring (3) and the upper spring cup (2), using tool 99360357 (6), compress the spring (3) and secure the parts to the valve with the split collets (1)

**!** The part of the spring with the more closely spaced coils (marked with paint) must face towards the head


**FITTING THE CYLINDER HEAD**



35099

To fit and tighten down the cylinder head, proceed as described below


- arrange the gasket (1) on the crankcase with the word ALTO (TOP) (2) facing the operator



35105


**!** To re-use a cylinder head bolt, check that at the point X shown, the diameter is 15.5 mm. If not, replace the bolt

**PUSHRODS**




35106

- position the cylinder head on the crankcase, lubricate the bolts and screw them down




35107

- tighten the bolts in the order shown in the figure and using the procedure described below
- stage 1, using a torque wrench (fig 164), carry out initial tightening to a torque of 118 Nm
- stage 2, retighten to a torque of 118 Nm




35102

- stage 3, fit tool 99395216 (1) to the angle gauge wrench and tighten by an angle of  $90^\circ \pm 3^\circ$
- stage 4, tighten by an angle of  $90^\circ \pm 3^\circ$
- stage 5, for bolts 1 to 14 only, tighten by an angle of  $45^\circ \pm 3^\circ$



32655


The valve pushrods must be free from distortion, the cup seatings for the adjustment screws and the ball ends locating in the tappets must not show any signs of seizing or wear, if they do, replace the rods  
Pushrods for inlet and exhaust valves are identical and therefore interchangeable



35109

Fit the pushrods (1) into their seatings


**ROCKER SHAFT  
ROCKERS**



32658

COMPONENT PARTS OF THE ROCKER SHAFT  
1 Circlip - 2 Adjustment shims - 3 Rockers - 4 Pedestal for shaft - 5 Spring - 6 Shaft






35110

MAIN DATA FOR ROCKER SHAFT PEDESTALS, ROCKER SHAFT AND ROCKERS


Check that the contact surfaces of the rockers with the shaft and of the shaft with the pedestals are not excessively worn or showing deterioration  
 Check that the plugs fitted to the ends of the shaft provide a perfect seal

**Fitting the rocker shaft and adjusting the operating clearance between the valves and rockers**



35111

Fit the caps onto the valve stems  
 Fit the rocker shaft assembly (1)  
 Tighten the nuts (2) securing the pedestals (3) to a torque of 50 Nm, then tighten them a further 90°, using tool 99395216 to check this



35112

Using wrench 99350108 (1), a feeler gauge (2) and a bi-hexagon wrench (3), adjust the clearance between the valves and rockers as indicated below

- rotate the crankshaft until the valves of no 1 cylinder are rocking and adjust the valves marked with an asterisk as shown in the table

cylinder no	1	2	3	4	5	6
inlet	-	-	*	-	*	*
exhaust	-	*	-	*	-	*


- rotate the crankshaft until the valves of no 6 cylinder are rocking and adjust the valves marked with an asterisk as shown in the table

cylinder no	1	2	3	4	5	6
inlet	*	*	-	*	-	-
exhaust	*	-	*	-	*	-

**LUBRICATION**

Engine lubrication is obtained by means of a gear type pump (fig 173) fitted to the lower part of the crankcase in line with the front main bearing, it is driven by the crankshaft gear

**OIL PUMP**




35113

SECTIONAL VIEW OF THE OIL PUMP  
 1 Pump body - 2 Driving gear - 3 Cover  
 - 4 Oil pump drive gear - 5 Driven gear

Check that the gears (2, 4 and 5) are not worn or showing deterioration and that their shafts do not have excessive play in the housings in the body (1) or the cover (3)  
 If any fault is found, replace the oil pump complete

**HEAT EXCHANGER**




35114

Remove the attachment screws (1) and take off the cover (2)  
 Remove the attachment screws (3) and take off the heat exchanger (4)




The following components are housed in the heat exchanger mounting the pressure relief valve, setting 7.5 bars, the fine filtered oil delivery regulation valve, setting pressure 4 bars

**Pressure relief valve**



35115


Remove the screw (2) securing the bracket (3) retaining the pressure relief valve (1) and remove the valve from the heat exchanger mounting (4)



35116


COMPONENT PARTS OF THE PRESSURE RELIEF VALVE  
 1 Valve body - 2 Seal - 3 Spring - 4 Valve  
 - 5 Circlip

Remove the circlip (5) and withdraw the spring (3) and the valve (4) from the valve body (1)  
 Check that the valve (4) slides freely in the valve body (1) without excessive play




35117

MAIN DATA FOR CHECKING THE RELIEF VALVE SPRING




Position the gasket on the crankcase and fit the sump (1)  
Fit the brackets




Fit the alternator bracket (2), the water pump (4) and pipes (4 and 5), fit and adjust the pulse transmitter as follows

- screw in the transmitter (3) until contact occurs
- unscrew one turn, corresponding to a gap of 1 mm
- tighten the lock nut to a torque of  $40 \pm 12$  Nm




Then fit the heat exchanger (2) and the compressor (1)



Fit the thermostat housing (5) and attach the pipe (2) to it

Refit the flange (3) to the water pump (4)

Fit the alternator to the alternator bracket (1) with the drive belt




35131

If a different value is found, adjust the tension of the belt (1) by means of the tensioner (2)




After the engine has run for a period of 1 h, again check that the tension is 40 – 50 daN, if not, adjust the belt tension once again

Fit the viscostatic fan (3) and secure it to the pulley (4) by means of the nuts (5)




35132

Fit the fan shroud (1)




34975

Fit the mounting (5) and screw the inhibitor filter (6) onto it  
Connect pipes (3 and 4) to the water pump (2)  
and pipe (1) to the mounting (5) and to the water pump (2)




35133

To clean the oil breather filter, mark the position in which the cover (4) is fitted to the rocker cover (1) and remove the filter  
Remove the circlip and take out the filter components (2)




35974

Fit the valve gear covers (1)  
Connect the oil breather pipe (3) to the breather (2) and secure it to the crankcase




34973

Fit the turbocharger (2) to the exhaust manifold (3) and refit the manifold to the cylinder head  
 Connect oil pipe (4) to the support (6) and oil pipe (5) to the coupling on the crankcase. Fit the air duct (1)




34970

Connect pipe (5) to the injection pump (6), pipe (3) to the fuel recovery pipe (4), pipe (1) to the thermostarter




34972

Fit the inlet manifold (3) and the injectors (2)  
 Connect the fuel delivery (1) and fuel return (4) pipes to the injectors



34971

Fit the fuel filters. Connect pipes (4 and 6) to the filter mounting (5) and to the injection pump (8), pipe (2) to the inlet manifold (1) and to the LDA device (3), pipe (7) to the injection pump (8)




34969

Fit the air duct (2) and the sleeve (1) for the oil level dipstick


## OVERHAULING THE TURBOCHARGER TYPE KKK, K27.2

### Preliminary checks



35137

Thoroughly clean the outside of the turbocharger using anti-corrosion and anti-oxidising liquids  
Mark the assembly position of the compressor body (3) to the flange (2) and of the flange to the centre body (1). Separate the compressor body (3) from the flange (2) by removing the retaining screws (4)




35138

Mark the assembly position of the turbine body (2) on the centre body (1)  
Remove the securing screws and separate the centre body (1) from the turbine body (2)



After detaching the turbine and compressor bodies and before proceeding to check the play in the bearings, check that the above components and the centre body are free from wear or erosion or foreign object impacts, also, there should be no carbonised oil present in the oil outlet port  
If even one of these points is found, replace the turbocharger complete

### Checking bearing play




35139



The end and radial play in the bearings should be measured on the shaft at the turbine rotor (2) end


Position the stylus of the dial gauge (1) with magnetic base on the spindle (2) and zero the dial gauge  
Press the spindle (2) in the directions shown by the arrows and check that the end play in the bearings is no more than 0.16 mm



35140


Position the stylus of the dial gauge (1) on the spindle (2) at the point shown in the figure. Using a spring balance (3), pull down on the spindle with a force of 50 N and zero the dial gauge in these conditions. Still with a force of 50 N, pull up on the spindle and measure the spindle deflection on the dial gauge  
This should be not more than 0.42 mm  
Repeat the check at one other point at least on the spindle

**Assembling**




32802

Using pliers (4), fit the inner circlips (3) to the centre body (5), insert the bushes (2) lubricated with engine oil and secure them with the outer circlips (1)



32805


Position the circlip (2) in its housing on the turbine rotor shaft (1)



35143


Lubricate the turbine rotor shaft (2), fit the heat shield (3), fit the centre body (1)  
When compressing the circlip (4), make sure that the opening is 90° away from the oil feed hole

**!** The circlip (4) is correctly positioned in its housing if the heat shield (3) and centre body (1) rotate freely




35144

Position the washer (3), spacer (2) and axial bearing (1) in the centre body (4)




35145

Fit the thrust washer (2) and the oil thrower (1)




35146

Fit the bush (2) complete with circlip (3) to the flange (1)




Fit the inner seal (2) to the flange (1) and fit this to the centre body (3), lining up the marks made when dismantling

**!** The seal (2) must be coated with NEVER-SEEZ compound




Apply LOCTITE 640 to the threads of the screws (1) and tighten them to a torque of 6 Nm (0.6 kgm)




Heat the compressor rotor (1) to 130°C. Lubricate the rotor shaft (3) and fit the compressor rotor (1) to this. Screw on a new securing nut and tighten it to a torque of 7 + 2 Nm, (0.5 + 0.2 kgm). After about 10' apply LOCTITE 640 to the threads of the shaft, unscrew the nut by 1 - 2 turns and retighten it to a torque of 5 + 0.6 Nm (0.5 + 0.6 kgm)

To conclude, seal the shaft nut and thread with locking varnish and check the end and radial play in the bearings as described on page 153



Fit the centre body (1) complete into the turbine body (2), taking care to line up the marks made when dismantling. Tighten the screws securing the centre body to the turbine body to a torque of 20 Nm (2 kgm)

**!** The threads of the turbine body securing screws must be coated with NEVER-SEEZ compound beforehand



Position a new seal (3) in the housing on the intermediate disc (2) and fit the compressor body (1) to the centre body (4), taking care to line up the marks made when dismantling. Tighten the screws securing the compressor body to the centre body to a torque of 7 Nm (0.7 kgm)

**!** Before fitting the turbocharger to the engine, the centre body should be filled with engine lubricating oil